


# Quick Installation Guide


LTE-Advanced Mobile Wi-Fi  
M7310

## Install the SIM Card and Battery


1 Remove the back cover.



2 Slide and lift up the SIM card slot cover.




3 Insert the SIM card and slide the cover back to lock.




- Nano SIM card must be converted using the provided SIM card tray.
- The SD card slot can be used for storage and media sharing.
- SIM card and SD card are not included.

4 Install the provided battery.




5 Note down the default SSID and Wireless Password.




6 Replace the cover.





## Connect to the Internet

1 Press and hold the  button until the splash screen appears.




- To power off, press and hold the  button until the "Power Off" appears on the screen.

2 You will see one of the following messages on the screen. Please follow the corresponding instructions to enjoy the Internet.



Connect to your Mobile Wi-Fi:





On your wireless device, select the default **SSID** and enter the **Wireless Password** which you have noted down.

Enjoy!



Enter the PIN :


On your wireless device, launch a web browser and enter <http://tplinkmifi.net> in the address bar, enter **admin** for Password, and then click **Login**. Enter the PIN according to your Carrier, and click **Done**.

- If other messages display on the screen, please refer to FAQ > Q3.
- For power saving, the Mobile Wi-Fi will turn off the Wi-Fi connection if no wireless devices are connected to the Mobile Wi-Fi for 10 minutes. Press the  or  button to resume the Wi-Fi connection.

# Screen Display


The screen display will automatically turn off after being idle for 15 seconds. Press the or button to turn it on again.

## Home Screen



## Menu Screen

Select the icons to access the various functions of the Mobile Wi-Fi. You can view and change settings on the corresponding screen.



- Signal Strength
- Wi-Fi Status and Connected Wi-Fi Devices
- Network Type and Internet Connection
- Battery Life
- Data Roaming
- Cumulative Data Usage
- Message
- Download Speed

- Home
- Device Info
- Power Saving
- Data Roaming
- WPS
- Wi-Fi Band
- Network Mode
- App Download

# tpMiFi App

Download the tpMiFi App (for iOS and Android) to conveniently manage your Mobile Wi-Fi.

- Modify Wi-Fi settings
- Send and receive SMS
- Manage battery
- Share files on the SD card
- Block devices

## How to download?


- Search for the tpMiFi App from the Apple Store or Google Play, or scan the QR code.
- Connect your wireless device to the Mobile Wi-Fi.
- Launch tpMiFi and enter **admin** to log in.



# Charging Your Mobile Wi-Fi


## Method 1

Via a Wall Outlet (Recommended)



## Method 2

Via a Computer



When the on the battery icon disappears, the Mobile Wi-Fi is fully charged.

# FAQ (Frequently Asked Questions)

## Q1. Is there an alternative to manage the Mobile Wi-Fi besides the tpMiFi app?

A. You can manage the Mobile Wi-Fi by using its web management page.

- Connect your wireless device to the Mobile Wi-Fi.
- Launch a web browser and enter <http://tplinkmifi.net> or <http://192.168.0.1> into the address bar. Enter **admin** for the Password, and then click **Login**.

## Q2. What should I do if I cannot log into the web management page?

- Verify that your device is connected to the Mobile Wi-Fi.
- Verify that you have entered <http://tplinkmifi.net> or <http://192.168.0.1> correctly.
- Verify that your device is set to obtain an IP address automatically.

## Q3. What should I do when one of the following messages appears on the screen or I cannot access the Internet?

### A1. PIN Required

- Log into the web management page. Enter the PIN according to your carrier, and click **Done**.

### A2. No SIM Card

- Power off the Mobile Wi-Fi and reinstall the SIM card.

### A3. No Service

- Verify that your SIM card is an LTE, WCDMA or GSM SIM card;
- Verify that your SIM card is in your carrier's service area and has sufficient credit;
- Verify that your carrier parameters are correct:

On your phone, log into the web management page, go to **Dial-up > View profile details** to verify if APN, Username and Password are correct. If not, return to the **Dial-up** page and create a new profile with the correct information. Then click **Done** and confirm at the prompt.

### A4. icon

- Press the and buttons to select **Data Roaming**, and then turn on **Data Roaming**.

## Q4. What should I do if my Internet speed is slow?

A1. If you are experiencing intermittent slow Internet connection, you can switch between 2.4GHz and 5GHz bands for better connectivity. From the Menu screen, go to **Wi-Fi Band**.

A2. The 4G network may be temporarily unavailable in your current location. From the Menu screen, go to **Network Mode** and try a different network.

## Q5. How do I restore the Mobile Wi-Fi to its factory default settings?

A. While the Mobile Wi-Fi is powered on, remove the cover. Use a pin to press and hold the **RESET** button until the **"Power Off"** appears on the screen.

Note: Restoring the Mobile Wi-Fi to its factory defaults will clear all previous settings and you have to reconfigure it.

## Safety Information

- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device.
- Do not use damaged charger or USB cable to charge the device.
- Do not use any other chargers than those recommended.
- Do not use the device where wireless devices are not allowed.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.