



Quick Start

Thank you for purchasing the Mobile WiFi. This Mobile WiFi brings you a high speed wireless network connection.

This document will help you understand your Mobile WiFi so you can start using it right away. Please read this document carefully before using your Mobile WiFi.

For detailed information about the functions and configurations of the Mobile WiFi, refer to the online help on the web management page that comes with the Mobile WiFi.

For detailed instructions for logging in to the web management page, refer to "Logging In to the Web Management Page".

Getting to Know Your Mobile WiFi

Note:

The Mobile WiFi function descriptions and illustrations in this document are for your reference only. The product you have purchased may vary.

Application Scenarios


Wi-Fi devices (such as smartphones, tablet computers, and game consoles) or computers can all access the Internet through Mobile WiFi. The specific connection procedure depends on the operating system of the Wi-Fi device or computer. Establish a connection according to your device's specific instructions.

To access the Internet through a USB port connection, install the driver according to the instructions.

Scenario 1: Accessing the Internet Using an LTE, 3G, or 2G Network


The Mobile WiFi uses your operator's LTE, 3G, or 2G network to access the Internet.

a) Wi-Fi or USB connection



b) Ethernet port connection (LAN)

Connect the Mobile WiFi to AF18, and then connect the AF18's network port to a computer using a network cable.




Note:

The AF18 is an optional accessory. If it is not included in the package, you can purchase one separately.


Scenario 2: Accessing the Internet Using a Wi-Fi Network

The Mobile WiFi supports the Wi-Fi extender function. When you use the Mobile WiFi in Wi-Fi coverage areas, for example, an airport, cafe, hotel, or your home, your Mobile WiFi will connect to known Wi-Fi hotspots, helping you save mobile data usage. For details about adding Wi-Fi hotspots, see "Adding a Wi-Fi Hotspot".




Scenario 3: Accessing the Internet Using Ethernet (WAN)


Connect the Mobile WiFi to AF18, and then connect the AF18's network port to the Ethernet port using a network cable. You can then access the Internet via Ethernet, such as a home ADSL, hotel DHCP, or campus static IP broadband network.



Appearance



- ❶ Power indicator
- ❷ Screen
- ❸ Micro USB port



- ❹ MENU button
- ❺ Power button

Screen

Home screen

❶ Roaming

R: Data roaming turned on.

❷ Signal strength

▬ ▬ ▬ ▬ ▬ ▬ ▬ ▬ ▬ ▬: Signal strength from weak to strong.

❸ Network type


- 4G/3G/2G: Connected to an LTE/3G/2G network.
- 📶: Connected to WLAN.

❹ Data connection status

❺ Battery

❻ SMS

- New messages.
- Number of new messages.



⑦ **Wi-Fi**

- Wi-Fi turned on.
- Number of connected Wi-Fi devices.
- 5GHz turned on.

⑧ **Traffic statistics**

- Data usage this month.
- Monthly data usage limit.

Note:

- To set the start date of the monthly data usage statistics and data usage limit, go to the web management page.
- Data traffic information is for your reference only. For more accurate data traffic information, please consult your service provider.

Menu screen


Press the **MENU** button to display the menu.


❶ Back

Return to the previous screen.

❷ Options

❸ Operation tips


- Press the **MENU** button to scroll down
- Press the  button to confirm your selection.




Update screen


When updates are available, you will be prompted to update the Mobile WiFi.

① Update

When **Update** is selected, press the  button to update the Mobile WiFi.

② Ignore

When **Ignore** is selected, press the  button to ignore the update.




SSID and Wireless Network Encryption Key

When a Wi-Fi device establishes a connection to the Mobile WiFi for the first time, you may need to enter the default Service Set Identifier (SSID) and wireless network encryption key.


The default SSID and encryption key are printed on the Mobile WiFi label.

It is recommended that you can log in to the web management page and change your SSID and wireless network encryption key.




To view the current SSID and wireless network encryption key on the screen:

1. Press the **MENU** button to display the menu.



2. Press the **MENU** button to scroll to **Device Info**.




3. Press the **OK** button to enter **Device Info**.



Getting Started

Installing

Install the micro-SIM card and microSD card according to the illustration.



Note:

- When removing the micro-SIM/microSD card, open the tab and gently press the micro-SIM/microSD card in, then release. The card will automatically pop out.
- Do not remove the micro-SIM/microSD card when it is in use. Doing so will affect the performance of your Mobile WiFi and data stored on the micro-SIM/microSD card may be lost.

- The microSD card is an optional accessory. If no microSD card is included in the package, please purchase one separately.

Charging the Battery


The device has a built-in, non-removable battery. Do not attempt to remove the battery, otherwise the device may be damaged. To replace the battery, take the device to an authorized service center.

If the Mobile WiFi has not been used for a long time or if the battery is fully depleted, the Mobile WiFi may not power on immediately after the charger is plugged in. Please charge the battery for a while before attempting to power on the Mobile WiFi.

Method 1: Use the charger to charge the device

Note:

- Only use chargers compatible with the Mobile WiFi and provided by a designated manufacturer. Use of an incompatible charger or one from an unknown




manufacturer may cause the Mobile WiFi to malfunction, fail, or could even cause a fire. Such use voids all warranties, whether expressed or implied, on the product.

- The charger is an optional accessory. If it is not included in the package, you may contact an authorized dealer to buy a charger compatible with the Mobile WiFi.
- The Mobile WiFi's charger model is HW-050200XYW. X and Y represent letters or numbers that vary by region. For details about the specific charger model, contact an authorized dealer.


Method 2: Charge the device through a computer connection

Use the data cable provided with your device to connect the Mobile WiFi to the computer.



Supplying Power to Devices

You can connect the Mobile WiFi to the power supply cable, and then connect the power supply cable to other devices, such as a mobile phone, music player, or Bluetooth headset. In this case, the Mobile WiFi works as a charger and supplies power to those devices.



Note:



The power supply cable is an optional accessory. If it is not included in the package, you can purchase one separately.


Turn on the Mobile WiFi

Press and hold the  button until the screen lights up, indicating that the Mobile WiFi is turned on.

You can log in to the web management page and turn the fast boot function on or off. This function greatly reduces the Mobile WiFi's boot-up time.

Note:

- Press and hold the  button to turn off the Mobile WiFi.
- If your Mobile WiFi malfunctions or cannot be properly powered off, press and hold the  button for at least 10 seconds to forcibly power off your Mobile WiFi.



Connecting to the Internet

Using an LTE, 3G, or 2G Network


The Mobile WiFi's management parameters have been preset according to your operator's requirements.

If data is transmitted, the Mobile WiFi will automatically connect to the Internet. If data is not transmitted for a period of time, the Mobile WiFi will automatically disconnect from the network connection.

Note:

You can log in to the web management page and enable or disable the automatic dialing while roaming function. If this function is turned off, when the Mobile WiFi enters a roaming network, it will automatically disconnect from the Internet connection that has already been established. You will need to manually establish this network connection again.


Using a Wi-Fi Network

1. Ensure that the Wi-Fi extender function is enabled.
2. The Mobile WiFi automatically connects to a Wi-Fi hotspot set by your service provider or yourself. When the Mobile WiFi is connected to a Wi-Fi network,  and the Wi-Fi hotspot SSID are displayed on the screen.

Note:

- After connecting to a Wi-Fi network, the Mobile WiFi automatically reconnects to the network the next time you are under that network's coverage.
- For details about adding Wi-Fi hotspots, see "Adding a Wi-Fi Hotspot".

Using Ethernet (WAN)

1. Connect the Mobile WiFi to the AF18.
2. Use the network cable to connect the AF18 to the router.
3. Make sure  appears on the screen.
4. Log in to the Mobile WiFi's web management page and configure the parameters of the Ethernet connection.
 - Dynamic IP: Does not need to be configured.
 - PPPoE: Enter the user name and password for a dial-up connection.
 - Static IP: Select static IP in connection mode and enter the IP address, default gateway address, DNS server address, and so on.

Note:

For detailed information about the user name, password, IP address, default gateway address, DNS server address, and other settings, contact your operator.

Logging In to the Web Management Page

1. Make sure the connection between the Mobile WiFi and the Wi-Fi device or computer is working normally.
2. Open the browser, and enter **http://192.168.8.1** in the address box.

Note:

If the IP address conflicts with other IP addresses on the network, the IP address of the Mobile WiFi automatically changes. Check the current IP address on the Mobile WiFi screen.

3. Enter the user name and password to log in to the web management page.

Note:

- The default user name is **admin**.
- The default password is **admin**.

Verifying the PIN

If the Mobile WiFi's network parameters have been correctly configured but you cannot access the Internet after powering it on, PIN verification may be enabled. Log in to the web management page and enter the PIN when prompted. To avoid entering the PIN every time you power on the Mobile WiFi, disable PIN verification from the web management page.


The PIN/PUK is delivered with your SIM card. For more details, contact your service provider.

Battery Saving Mode

If the Mobile WiFi has been inactive for some time, the Mobile WiFi enters the standby mode, in which the display screen turns off. Pressing any button causes the display screen to light up.

When the Mobile WiFi is being powered only by the battery, you can choose to enable or disable the automatic Wi-Fi off function. If this function is enabled and if no Wi-Fi devices access the Mobile WiFi for a period of time, the Wi-Fi turns off automatically. You can press any button to turn the Wi-Fi on again.

Turning Wi-Fi extender On or Off


1. Press the **MENU** button to display the menu.
2. Press the **MENU** button to scroll to **Wi-Fi extender**.
3. Press the  button to turn Wi-Fi extender on or off.

Note:

- Alternatively, you can log in to the Mobile WiFi's web management page to enable or disable Wi-Fi extender.
- After the Wi-Fi extender function is enabled, up to nine Wi-Fi devices can be connected to the Mobile WiFi.

Adding a Wi-Fi Hotspot



1. Log in to the web management page.
2. From the settings page, choose **Wi-Fi extender**.
3. Scan for Wi-Fi hotspots and connect to the desired one.



Downloading the HUAWEI Mobile WiFi App for an Android

Device Using a 2D Barcode

On the Mobile WiFi:


1. Press the **MENU** button to display the menu.
2. Press the **MENU** button to scroll to **2D Barcode**.
3. Press the  button to enter **2D Barcode**.
4. Press the **MENU** button to scroll to **Mobile app**.
5. Press the  button to display the **Mobile app** screen.

On your Android device:

6. Scan the 2D Barcode on the Mobile WiFi to download the HUAWEI Mobile WiFi App.



Note:

Alternatively, you can search for **HUAWEI Mobile WiFi** in Google Play or HUAWEI App Center and download the app to your device.



Connecting an Android Device to the Mobile WiFi Using a 2D Barcode


On the Mobile WiFi:

1. Press the **MENU** button to display the menu.
2. Press the **MENU** button to scroll to **2D Barcode**.
3. Press the  button to enter **2D Barcode**.
4. Press the **MENU** button to scroll to **Wi-Fi key**.
5. Press the  button to display the **Wi-Fi key** screen.

On your Android device:

6. Scan the 2D Barcode on the Mobile WiFi using the HUAWEI Mobile WiFi App.


Your Android device will then connect to the Mobile WiFi.



Establishing a WPS Connection

If the Wi-Fi device to be connected to the Mobile WiFi supports WPS, the wireless network encryption key is generated automatically and there is no need to enter it manually.

The steps for WPS connection are as follows:

1. Turn on the Mobile WiFi.
2. Turn on the Wi-Fi device to be connected to the Mobile WiFi.
3. Press the **MENU** button to display the menu, scroll to **WPS**, and then press the  button to activate Mobile WiFi's WPS.
4. Activate the Wi-Fi device's WPS.

Note:


For specific instructions for the Wi-Fi device, refer to the device's user manual.



Restoring to Factory Settings

If you forget the user name, password, or SSID you have set, you can restore the settings on the web management page to their factory values.

To do so, simply press and hold the **Reset** button until the Mobile WiFi restarts.



Example 1: Establish a Wi-Fi connection (using a computer running the Windows 7 operating system as an example)

1. Ensure that the Mobile WiFi's Wi-Fi function is on.
2. Select **Start > Control Panel > Network and Internet > Network and Sharing Center > Connect to a network.**

Note:

Before establishing a Wi-Fi connection, ensure that the computer is equipped with a wireless network adapter. If the computer indicates a wireless network connection, the wireless network adapter can be used. Otherwise, verify that your wireless network adapter is working properly.

3. Select the wireless network connection with the Mobile WiFi's SSID and click **Connect.**

Note:



- If the wireless network connection is encrypted, enter the correct wireless network encryption key.
- To view the current SSID and wireless network encryption key, see the operations in the

“SSID and Wireless Network Encryption Key” section.



4. Wait a moment for the wireless network connection icon to appear in the system tray in the lower right corner of the computer screen. The wireless network connection is then established.

Example 2: Connecting to a Game Console (for example, PSP) through Wi-Fi

1. On the PSP, turn on the WLAN.
2. Choose **Settings** > **Network Settings**.
3. Select **Infrastructure Mode**.
4. Select **New Connection**, and enter the connection name.
5. Select **Scan** to search for wireless networks. A list of access points will be displayed on the screen.
6. Select the access point with the Mobile WiFi's SSID, and press the **▶** button on the PSP. Confirm the SSID, and enter the correct wireless network encryption key.
7. Press the **▶** button to proceed to the next step, and then press the **X** button to save settings.



8. Select **Test Connection** to test whether the network connection is successful.
9. You can now open the browser and access the network.




Example 3: Connecting to a Tablet Computer (for example, iPad) through Wi-Fi

1. Touch **Settings** > **WLAN** to turn on WLAN.
2. The tablet computer automatically searches for wireless connections and displays a list of access points.
3. Select the access point with the Mobile WiFi's SSID.
4. If required, enter the correct wireless network encryption key, and tap **Join**.
(The lock icon indicates that the encryption key is required to connect to this wireless network.)

Note:

Wi-Fi devices, such as an iPhone, iPod touch, PS3 and NDSi, can all access the Internet through the Mobile WiFi. For specific operations, refer to the Wi-Fi device's user manual.



Tips

When the Mobile WiFi is in use for an extended period of time, it will become warm and may overheat. Should this happen, the Mobile WiFi will automatically close the network connection and turn off to protect itself from damage. If this occurs, place the Mobile WiFi in a well ventilated space to allow the heat to dissipate, then turn it on and continue to use it as normal.

If you are unable to use the Mobile WiFi as normal, try the following:

- Consult the online help on the web management page.
- Restart the Mobile WiFi.
- Restore the Mobile WiFi to the factory settings.
- Consult your operator.

 **lte**[™] is a trademark of ETSI.